



## DATA SHEET

 For waterfilled

### Valve type 121

Type:	Thermostat angel valve.
Thermostat:	Yes - return flow left side.
Mounting:	½" thread into the radiator and ½" inside thread toward the wall.
Surfaces:	Chrome, white and steel.
Mounting distance:	From bottom of the radiator to center of the inside thread toward the wall is 35 mm.  From centre of the radiator thread to back of valve toward the wall is 35 mm.
Included into the box:	Plastic pipe coverings with rosettes in the same surface as the valve. The pipe coverings are 50 mm and the rosettes are Ø60 mm.