




## **DATA SHEET**



Thermostat angel valve.

## Valve type 120

Type:

Thermostat: Yes - return flow right side. ½" thread into the radiator and ½" inside thread Mounting: toward the wall. Surfaces: Chrome, white and steel. From bottom of the radiator to center of the inside Mounting distance: thread toward the wall is 35 mm. From centre of the radiator thread to back of valve toward the wall is 35 mm. Included into the box: Plastic pipe coverings with rosettes in the same surface as the valve. The pipe coverings are 50 mm and the rosettes are Ø60 mm.