


PLUS 2


Datasheet and mounting instruction will be available on our website

www.tvs.dk

FRONT OF THE HEATER



The cable goes out 35 mm from bottom of the vertical pipe



● = Bracket with cover rosette. The rosette covers 50 mm .